


# DDR3 DIMM Latch Tower Spreading Tool Application Tooling Specification Order No. 62100-1800



#### **FEATURES**

- Tool aligns on latch rib to spread tower.
- Latch can be extracted without removing neighboring memory cards.
- For actuator extraction, use tool 62100-9100.

### **SCOPE**

<u>Products</u>: DDR3 DIMM Socket 78468 Series Assembly (276 Circuit, Vertical SMT). See Product List below for specific part numbers.

#### **Product List**

The following is a partial list of the product order numbers and their specifications this tool is designed to run. Updates to this list are available on <a href="https://www.molex.com">www.molex.com</a>.


Series No.	Assembly Order Number	
78468	78468-0002 (DIMM Socket Assembly)	78468-2001 (Latch)


## **Tool Description**

The principal parts of the Tower Spreading Tool are shown in Figure 1.

# **Tool Operation**


- 1. Remove the Memory Card from the socket by pushing in the actuators.
- 2. Remove the actuator with tool 62100-9100. See Figure 2.






Doc No: ATS-621001800 Revision: A Release Date: 02-08-10 Revision Date: 02-08-10 **UNCONTROLLED COPY** 

3. After removing the actuator, use the spreading tool tip to flip the latch up. Align the slot of the tool with the rib of the latch. Push the tool straight down until its shoulders are touching the top of the tower. See Figure 3.



4. With the tool in position as shown in Figure 3, use a tweezers or small pliers to pull up the latch. (The tool will be in the way of the latch being fully removed.)




Doc No: ATS-621001800 Revision: A

Release Date: 02-08-10 Revision Date: 02-08-10

- Remove the spreading tool from the tower. Finish pulling the latch out of the tower. See Figure 5.
- The new latch can be installed by hand.

**CAUTION**: Molex application tooling specifications are valid only when used with Molex connectors and tooling.



# **Contact Information**

For more information on Molex application tooling please contact Molex at 1-800-786-6539.

Americas Headquarters Lisle, Illinois 60532 U.S.A. 1-800-78MOLEX amerinfo@molex.com

Far East North Headquarters Yamato, Kanagawa, Japan 81-462-65-2324 feninfo@molex.com

Far East South Headquarters Jurong, Singapore 65-6-268-6868 fesinfo@molex.com

**European Headquarters** Munich, Germany 49-89-413092-0 eurinfo@molex.com

**Corporate Headquarters** 2222 Wellington Ct. Lisle, IL 60532 U.S.A. 630-969-4550 Fax: 630-969-1352

Visit our Web site at http://www.molex.com

**UNCONTROLLED COPY** Doc No: ATS-621001800 Release Date: 02-08-10 Page 3 of 3 Revision Date: 02-08-10

Revision: A